Vector Network Analysers

TRACE-HISTORY

FEBRUARY 10, 2021

ROHDE&SCHWARZ

Make ideas real




BACKGROUND

From the manual:

"The [trace history] commands... retrieve the results of any sweep within a previously defined single sweep group. This means that, in single sweep mode, you can first measure a specified number of sweeps and then read any of the data traces acquired.

This feature has no equivalent in manual control..."



COMMAND LINE INTERFACE

```
usage: trace-history [--help] [--quiet] [--version]
[--ip-address IP_ADDRESS] [--log-file LOG_FILE] [--timeout-ms TIMEOUT_MS]
[--set-file SET_FILE] [--data-path DATA_PATH] sweep_count
```

positional arguments:

sweep_count

optional arguments:

--help show this help message and exit

--quiet do not print to stdout


--version show program's version number and exit

--ip-address IP_ADDRESS default: localhost --log-file LOG_FILE default: vna.log --timeout-ms TIMEOUT MS default: 120000

--set-file SET_FILE

--data-path DATA_PATH default: current working directory

ARCHITECTURE



^{*}see command line options

► at main:line 40:

```
# sweep, measure time¬
vna.manual_sweep = True¬
vna.sweep_count = args.sweep_count¬
total_time_s = default_time_s(vna.sweep)¬
time_per_sweep_s = total_time_s / args.sweep_count¬
```

► at main:line 43:

```
# sweep, measure time¬
vna.manual_sweep = True¬
vna.sweep_count = args.sweep_count¬
total_time_s = default_time_s(vna.sweep)
time_per_sweep_s = total_time_s / args.sweep_count¬
```

► Note: sweep_time_s \(\) total_time_s / sweep_count for large sweep_count

▶ from default_time:line 4:

```
def default_time_s(fn):-
    start_time_s = default_timer()-
    fn()-
    stop_time_s = default_timer()-
    return stop_time_s - start_time_s-
```

► from rohdeschwarz.instruments.vna.vna:line 472:


```
def sweep(self):=
    self.manual_sweep = True=
    timeout_ms = 2 * self.sweep_time_ms + 5000=
    self.start_sweeps()=
    self.pause(timeout_ms)=
```


ALGORITHM: SAVE RESULTS

- ► from main: line 56:
- ▶ Note that this is occurs *after* the sweep time estimate.

```
# save trace history
for name in vna.traces:
filename = str(data_path / f'{name}.csv')
vna.trace(name).save_complex_history_locally(filename)
```

- ► Taken from the <u>trace-history documentation</u>
- ▶ Note: displayed sweep time (21.8 ms) is considered a <u>rough estimate</u>.








- ► Batch script run with SWEEP_COUNT = [2, 200, 500, 1000, 2000]
- ► Script runs trace-history RUN_COUNT times

```
rem parameters
SET SWEEP_COUNT=100
SET RUN_COUNT=100
rem mkdir¤
SET
       DATA_PATH=sweep_count_%SWEEP_COUNT%
mkdir %DATA_PATH%
rem call trace-history
for /L %%i in (1, 1, 100) do (
  trace-history\trace-history.exe --data-path %DATA_PATH% %SWEEP_COUNT%
```

- ► Uncertainty relative to mean is high at SWEEP_COUNT=2
- ► Relative uncertainty is small at SWEEP_COUNT=200
- ► Relative uncertainty is negligible at SWEEP_COUNT=2000







Total Time Statistics					
Sweep Count	Runs	Min (ms)	Mean (ms)	Max (ms)	
2	100	0.0709	0.0711	0.0793	
200	10	6.9251	6.9270	6.9330	
500	10	17.3107	17.3129	17.3185	
1000	10	34.6193	34.6219	34.6334	
2000	10	69.2592	69.2453	69.2592	

Estimated Sweep Time Statistics						
Sweep Count	Runs	Min (ms)	Mean (ms)	Max (ms)		
2	100	35.4	35.6	39.6		
200	10	34.6	34.6	34.7		
500	10	34.6	34.6	34.6		
1000	10	34.6	34.6	34.6		
2000	10	34.6	34.6	34.6		

- ► Note: transients are largely averaged out at sweep_count=200.
- ▶ Note: estimated sweep time is approximately 59% *slower* than firmware estimate.